


FEIG ELECTRONIC VEK MNH OPERATING MANUAL



Quick Links

[Vehicle Detection](#)

[Loop Inputs](#)

[Dip Switch Settings](#)

Table of Contents

- Table of Contents
- Data protection and copy protection
- Disclaimer of liability
- Manufacturer
- Scope
- Information on the document
- Abbreviations
- Technical terms
- Scope of delivery
- Housing dimensions
- Device components
- Technical data
- Product versions
- Product characteristics
- Product functions
- Vehicle detection
- Output signals
- Alignment of the loop channels
- Scanning of the loop channels
- Loop error detection
- Power supply
- Loop inputs
- Signal outputs
- Relay outputs with changeover contact
- Open collector outputs
- Assembly on the DIN rail TS35
- Connecting the power supply
- Connect the relay outputs (versions -R24)
- Connecting the open collector outputs (versions -O24)
- Connecting the induction loops
- LED status indicators
- DIP switch settings
- Reset button
- USB interface
- Detector Tool service program

Adjusting sensitivity (switch-on threshold)
Setting hysteresis (switch-off threshold)
Setting loop frequency (frequency step)
Setting hold time
Setting output mode (signal type)
Inverting output signal (Signal behaviour)
Behaviour in the event of loop error (error mode)
Assigning an output to a loop (Assignment)
Setting output switching time (impulse time)
Setting output times (output time behaviour)
Setting direction detection (dual-channel variants)
Setting direction logic (dual-channel variants)
Single vehicle" direction logic
Queue" direction logic
Wrong-way driver" 1 direction logic
Wrong way driver 2" direction logic
Manoeuvring" 1 direction logic
Manoeuvring" 2 direction logic
Wrong-way driver in queue" direction logic
Direction Logic „Cross traffic
Direction Logic „Parking bay
Accessories
Declaration of conformity
Other ManualsLib Projects

VEK MNH

Traffic detector

Operating manual


EN

IMPORTANT!

Read carefully before use!

Keep for future reference!

Safety instructions on page 12!



DE ACHTUNG!
WICHTIGE SICHERHEITSHINWEISE!
Folgen Sie den Anweisungen auf Seite 3 dieser Anleitung.

ES ¡ATENCIÓN!
¡INDICACIONES IMPORTANTES DE SEGURIDAD!
Deben seguirse las indicaciones detalladas en página 3 de estas instrucciones de montaje.

NL LET OP!
BELANGRIJKE VEILIGHEIDSINSTRUCTIES!
Volg de instructies op pagina 3 van deze montagehandleiding op.

FR ATTENTION!
IMPORTANTES INDICATIONS DE SÉCURITÉ!
Les instructions de la page 3 de cette notice de montage doivent être observées strictement.

IT ATTENZIONE!
INDICAZIONI SULLA SICUREZZA IMPORTANTI!
Prestare attenzione alle note alla pagina 3 delle presenti istruzioni di montaggio.

DA PAS PÅ!
VIGTIGE SIKKERHEDSANVISNINGER!
Oplysningerne på side 3 i denne monteringsvejledning skal følges.

DE ACHTUNG! WICHTIGE SICHERHEITSANWEISUNGEN!

Für die Sicherheit von Personen ist es wichtig diesen Anweisungen Folge zu leisten.
Diese Anweisungen sind aufzubewahren.
Diese Anleitung finden Sie im Kundencenter unter <https://www.feig.de/login/>.
Bitte loggen Sie sich mit folgenden Zugangsdaten ein. Benutzername: Download / Passwort: feig

EN ATTENTION! IMPORTANT SAFETY INFORMATION!

These instructions must be observed to ensure personal safety.
Store these instructions safely.
These instructions are available from the customer center at <https://www.feig.de/en/login/>.
Please sign in with the following details: Username: Download / Password: feig

FR ATTENTION! IMPORTANTES INDICATIONS DE SÉCURITÉ!

Pour la sécurité des personnes, il est important de respecter les consignes en question.
Les présentes consignes doivent être conservées en lieu sûr.
Les instructions sont téléchargeables dans le centre de clientèle de <https://www.feig.de/en/login/>.
Prière de vous logger avec les données suivantes. Username: Download / Password: feig

ES ¡ATENCIÓN! INDICACIONES IMPORTANTES DE SEGURIDAD

Para la seguridad de las personas es importante seguir estas indicaciones.
Deben guardarse estas indicaciones.
Puede encontrar estas instrucciones en el Centro de atención al cliente en <https://www.feig.de/en/login/>.
Se ruega iniciar sesión con los siguientes datos de acceso: Username: Download / Password: feig

IT ATTENZIONE! INDICAZIONI SULLA SICUREZZA IMPORTANTI!

Per la sicurezza personale è importante attenersi scrupolosamente a queste indicazioni.
Queste indicazioni vanno conservate.
Le presenti istruzioni sono disponibili nell'area clienti del sito <https://www.feig.de/en/login/>.
Effettuare il login con i seguenti dati d'accesso: Username: Download / Password: feig

NL LET OP! BELANGRIJKE VEILIGHEIDSINSTRUCTIES!

Voor de veiligheid van personen is het belangrijk om deze aanwijzingen op te volgen.
Deze aanwijzingen dienen bewaard te worden.
Deze handleiding kunt u vinden in het Customer Center op <https://www.feig.de/en/login/>.
Gelieve de volgende toegangsgegevens te gebruiken. Username: Download / Password: feig

DA PAS PÅ! VIGTIGE SIKKERHEDSANVISNINGER

For sikkerheden af personer er det vigtigt at følge disse anvisninger.
Disse anvisninger skal opbevares.
Denne monteringsvejledning finder du i downloadområdet på <https://www.feig.de/en/login/>.
Log på med følgende adgangsdata: Username: Download / Password: feig

The screenshot shows the FEIG ELECTRONIC website's login interface. At the top, there is a navigation bar with links for PRODUKTE, BRANCHEN, EVENTS, SERVICE, NEWS, KARRIERE, UNTERNEHMEN, and KONTAKT. A search bar labeled 'SUCHEN' is on the right. Below the navigation bar, there is a 'HOME_LOGIN' link. The main content area features a 'KUNDENCENTER' dropdown menu (callout 1) with options for 'EU-KONFORMITÄTSEKTLÄRUNG' and 'RETOUREN'. Below this is a 'BENUTZERANMELDUNG' section. It contains a form with fields for 'Benutzername:' (containing 'Download') and 'Passwort:' (containing 'feig') (callout 2). There is a link for 'Passwort vergessen?'. At the bottom of the form is an 'ANMELDEN' button (callout 3). To the left of the form, there is text in German providing instructions for users who have not yet registered or have forgotten their password.

Contents

1	Legal Notice	7
1.1	Data protection and copy protection	7
1.2	Disclaimer of liability	7
1.3	Manufacturer	8
1.4	Scope	8
2	General information	9
2.1	Information on the document	9
2.2	Abbreviations	10
2.3	Technical terms	11
3	Safety and warning information	12
4	Proper use	13
5	Product overview	14
5.1	Scope of delivery	14
5.2	Housing dimensions	15
5.3	Device components	16
5.4	Technical data	17
6	Product description	19
6.1	Product versions	19
6.2	Product characteristics	20
6.3	Product functions	20
6.3.1	Vehicle detection	21
6.3.2	Output signals	21
6.3.3	Alignment of the loop channels	21
6.3.4	Scanning of the loop channels	21
6.3.5	Loop error detection	21

7	Description of connections	22
7.1	Power supply.....	22
7.2	Loop inputs	22
7.3	Signal outputs	23
7.3.1	Relay outputs with changeover contact.....	23
7.3.2	Open collector outputs	24
8	Assembly and electrical installation	25
8.1	Assembly on the DIN rail TS35.....	25
8.2	Connecting the power supply	25
8.3	Connect the relay outputs (versions -R24).....	26
8.4	Connecting the open collector outputs (versions -O24)	26
8.5	Connecting the induction loops.....	27
9	Commissioning	28
10	Description of functions	29
10.1	LED status indicators	29
10.2	DIP switch settings	30
10.3	Reset button	33
10.4	USB interface.....	33
10.5	<i>Detector Tool</i> service program	33
11	Description of settings	35
11.1	Adjusting sensitivity (switch-on threshold)	36
11.2	Setting hysteresis (switch-off threshold)	37
11.3	Setting loop frequency (frequency step)	38
11.4	Setting hold time	39
11.5	Setting output mode (signal type).....	39
11.6	Inverting output signal (Signal behaviour)	40
11.7	Behaviour in the event of loop error (error mode)	40
11.8	Assigning an output to a loop (Assignment)	40
11.9	Setting output switching time (impulse time)	41
11.10	Setting output times (output time behaviour)	41
11.11	Setting direction detection (dual-channel variants).....	42

11.12	Setting direction logic (dual-channel variants)	44
11.12.1	"Single vehicle" direction logic	45
11.12.2	"Queue" direction logic	46
11.12.3	"Wrong-way driver" 1 direction logic	46
11.12.4	"Wrong way driver 2" direction logic	47
11.12.5	"Manoeuvring" 1 direction logic	47
11.12.6	"Manoeuvring" 2 direction logic	48
11.12.7	"Wrong-way driver in queue" direction logic.....	48
11.12.8	Direction Logic „Cross traffic“	49
11.12.9	Direction Logic „Parking bay“	50
12	Maintenance & servicing	51
13	Decommissioning	51
14	Key words	52
15	Appendix	54
15.1	Accessories	54
15.2	Declaration of conformity	54

1 Legal Notice

1.1 Data protection and copy protection

Translations of original documents

All versions of these documents that are not in the German language are translations of the original German operating instructions.

Validity of the documents

These instructions are only valid for the version of the product specified.

This edition replaces all earlier versions of the documents.

The information in this document is subject to change without notice.

Copyright

Full or partial photocopying or reproduction of these instructions, as well as translation into other languages, is not permitted without the prior written consent of FEIG ELECTRONIC. The full or partial storage of these instructions on modern information carriers for the purpose of subsequent processing on computers is also prohibited.

1.2 Disclaimer of liability

FEIG ELECTRONIC GmbH makes no guarantee for the correctness and completeness of the information in this manual. In particular, FEIG ELECTRONIC GmbH cannot be made liable for consequential damages due to erroneous or incomplete information.

The information in this document has been compiled according to the best of our knowledge and belief. Despite all efforts, it is never possible to completely exclude incorrect information. We are always grateful to receive information or enquiries.

The recommendations for installation contained in this document presume favourable general conditions. FEIG ELECTRONIC GmbH assumes no liability for the proper operation of the equipment in third-party environments.

FEIG ELECTRONIC GmbH provides no warranty that the information in this document is free from third-party intellectual property rights. By furnishing this document, FEIG ELECTRONIC GmbH does not grant any licenses to its own or third-party patents or any other intellectual property rights.

Guarantee claims against FEIG ELECTRONIC GmbH may only be made by the direct contracting party and are not transferable. Any guarantee only applies to the products supplied by FEIG ELECTRONIC GmbH. Any liability for the complete system is excluded.

The description of the products, their use, features and performance data does not count as guaranteed properties and is subject to technical changes.

1.3 Manufacturer

FEIG ELECTRONIC GmbH

Lange Straße 4

35781 Weilburg

Germany

Internet: www.feig.de

Email: info@feig.de

Telephone: + 49 (0) 6471 3109 – 0

1.4 Scope

Product type: Traffic detector

Product series: VEK MNH

Field of application: Accessory for traffic, door and barrier control

Document type: Operating manual

Original language: German

Document language: English

Document name: VEK MNH Operating Manual v1.3 en

Document version: rev3

Publication date: 25.11.2019

2 General information

NOTE

Read and keep instructions

Read this document before you use the product for the first time, and keep it in a safe place for future reference.

NOTE

Information in this document

This document refers to the default settings or default values defined by the manufacturer. The factory settings of customer variants may differ from the manufacturer's specifications. Please observe the instructions on the device, as well as the documents supplied with it.

2.1 Information on the document

This section explains the illustrations, instructions and information in this document.

⚠ CAUTION

Health hazard

Identifies a possible risk of injury to persons and provides instructions on prevention and avoidance.

WARNING

Damage to property

Identifies possible damage to property or provides information on the safety and function of the device.

NOTE

Information

Provides useful information on the nature and use of the device or document.

Prerequisite

Conditions for an action

Indicates the prerequisites for carrying out the following instructions.

Tools

Resources for an action

Indicates the tools required to carry out the instructions that follow.

Recommendation, example

Practical tips for application

Provides practical information and examples.

2.2 Abbreviations

Abbreviation	Meaning
CE	labelling to comply with the harmonisation legislation in accordance with EU regulation
COM	common terminal for relays with changeover contacts.
DIN	German industry standard
DIP	switch panel for default settings - Dual In-line Package
EMC	electromechanical compatibility
EN	European norm
GND	ground connection to power supply
IP 20	protection type of electrical equipment for environmental conditions and people
ISO	International Standards Organization
MNH	Traffic detectors series produced by FEIG ELECTRONIC GmbH
MR	machinery directive for the European Economic Area
NC	switch installed as opener (Normally Closed)
NO	switch installed as closer (Normally Open)
O24	product variants for 24 volts with open collector outputs (bipolar transistors)
OC	open collector connection
R24	product variants for 24 volts with relay outputs
RoHS	guidelines on pollution (Restriction of Hazardous Substances)
SELV	Safety Extra-Low Voltage
PLC	Programmable Logic Controller
UL	guideline for electrical safety (Underwriters Laboratories)
VAC	Volts of Alternating Current
VCC	Volts of Common Collector
VDC	Volts of Direct Current
VEK	sensor products made by FEIG ELECTRONIC GmbH
WEEE	directive on electrical waste (Waste Electrical and Electronic Equipment)

Tab. 1: Meaning of abbreviations

2.3 Technical terms

Technical term	Meaning
Switch-off threshold	Level of loop detuning until the output signal switches off
Induction loop detector	Sensor for detecting metallic objects by means of induction loops (coils)
Switch-on threshold	Level of loop detuning until the output signal switches on
Hysteresis	Difference in percent between the switch-on threshold and the switch-off threshold
LC oscillator	Electrical oscillatory circuit with coil and capacitor
Open collector	Bipolar transistor with internal blank collector output
Safety Extra-Low Voltage	Nominal voltage up to 50 VAC or 75 VDC and insulation against higher voltage for protection against electric shock (SELV)
Protection class III	Electrical safety protection class (see Safety Extra-Low Voltage)
Protection type IP	Protection type for environmental conditions (IP 20: protection against solid objects up to 12 mm, no protection against liquids)

Tab. 2: Explanation of technical terms

3 Safety and warning information

WARNING

Intended use

The device may only be used for the purpose intended by the manufacturer. Please read the section on proper use.

Availability of documents

The operating instructions must be available at all times. The instructions must be read and understood before the device is used for the first time, and adhered to at all times.

Service only by trained electricians

All work on the device hardware (assembly, connection, commissioning, maintenance, servicing, measurements and settings on the device) may only be carried out by qualified electricians with relevant training on the prevention of accidents.

Improper use

The device is subject to the manufacturer's guarantee conditions valid at the time of purchase. The manufacturer shall not accept any responsibility for incorrect manual or automatic parameter settings performed on a device or the inappropriate use of a device.

Improper repairs

Repairs may only be performed by the manufacturer. Failure to comply results in endangering the safety of the device and renders the warranty null and void.

Permitted power sources

The power supply must meet the requirements for safety extra-low voltage (SELV).

Regulations on electrical voltage

Users of devices which come into contact with electrical voltage are required to comply with the valid VDE regulations. These are in particular, but with no claim to completeness, VDE 0100, VDE 0550/0551, EN 60335 (VDE 0700), EN 60065 (VDE 0860), EN 50110 (VDE 0105), and the fire and accident-prevention regulations DGUV.

Observe national regulations

All work on the device and its installation must be carried out in accordance with the specifications of the national electrical regulations and local regulations.

Essential safety equipment

The device may not be used as a safety component as defined by the Machinery Directive 2006/42/EG, the Construction Products Regulation 305/2011/EU or other safety regulations. Systems posing a threat of danger require additional safety equipment.

⚠ CAUTION**Incorrect use**

Impermissible alterations to the device and the use of spare parts and additional devices not sold or recommended by the manufacturer of the device may result in fire, electric shocks and injury. Such actions shall therefore result in an exclusion of liability and forfeiture of the guarantee.

Impermissible interference with the housing

The housing may not be opened. This jeopardises the function and leads to forfeiture of the guarantee.



At the end of its service life, dispose of the product in accordance with the valid legal specifications.

4 Proper use

Induction loop detectors such as traffic detectors are operated in combination with various induction loops and electronic controller, such as frequency converters and PLC controller.

Areas of application are systems in the areas of traffic engineering, door and barrier controller, parking and tunnel monitoring as well as traffic light systems.

The traffic detectors of the VEK MNH series are intended for installation in a controller cabinet or a similar housing.

WARNING**Comply with the technical data**

The detector may only be operated with the prescribed supply voltages. Take note of the technical data before installation.

WARNING**Protection from environmental influences**

The device must be installed in a location where it will not sustain damage from heat, dripping water, moisture or dust.

5 Product overview

5.1 Scope of delivery

Product components
Traffic detector VEK MNH
Plug-in terminal blocks: 1x power supply, 1x loops, 2x relays or 2x open collector
Operating manual

Tab. 3: Scope of delivery

Downloads
Short description (multiple languages, as download under www.feig.de)
Operating instructions (multiple languages, as download under www.feig.de)
<i>Detector Tool</i> service program (multiple languages, as download under www.feig.de)
<i>Detector Tool</i> instruction manual (multiple languages, as download under www.feig.de)

Tab. 4: Download of product accessories

5.2 Housing dimensions




Fig. 1: VEK MNH2 side view




Fig. 2: VEK MNH2 front view

5.3 Device components




Fig. 3: Verkehrsdetektor VEK MNH

Index	Component	Description
A	Loop channel LEDs 1 (red + blue)	Status indicators for the loops and the detector
B	DIP switch 1	Basic settings for the detector
C	Loop channel LEDs 2 (red + blue)	Status indicators for the loops and the detector
D	DIP switch 2 (MNH2 variant)	Basic settings for the detector
E	USB connection	PC interface for configuration and diagnostics
F	Reset button	Factory settings or fresh adjustment
G	Loop inputs (orange)	Connections for induction loops
H	Output 1 terminal block: - Relay output 1 (yellow, R24 variant) - Open collector output 1 (green, O24 variant)	Signal outputs for controller
I	Mounting bracket	Mounting device for TS35 DIN rail
J	Output 2 terminal block: - Relay output 2 (red, R24 variant) - Open collector output 2 (green, O24 variant)	Signal outputs for controller
K	AC/DC connection (blue)	Connections for power supply

Tab. 5: VEK MNH Traffic Detector

5.4 Technical data

Specifications	
Housing	Plastic housing, ABS, blue
Mounting method	TS35 DIN rail
Dimensions	22.5 x 79.0 x 81.0 mm (W x H x L, without terminals)
Power supply (1 x blue)	2-pole terminal block (see Note 3) 10 – 30 VDC / 10 – 26 VAC, max. 2 W (SELV)
Power consumption	Typically 500 mW
Protection class	III
Protection type	IP20
Environmental conditions	
• permitted operating temperature	-37 – +70 °C
• permissible storage temperature	-40 – +85 °C
• relative humidity	< 95 % (non-condensing)
Loop properties	
• max. inductivity range	20 - 700 µH (see note 1)
• recommended inductivity range	100 – 300 µH
• operating frequency	30 – 130 kHz
• cable length	200 m
• internal resistance	20 Ω (including cable)
• min. insulation resistance to earth	100 kΩ (constant, including cable)
• insulation voltage, loop inputs	1 kV (galvanic isolation)
Cycle and reaction time	12 ms (independent of loop channels)
Maximum speed for vehicles	
• presence detection	Max. 200 km/h
• direction detection (dual-channel variants)	Max. 200 km/h (at loop head distance of 2 m)

Specifications	
Inputs	
• 1 x loop (1 x orange, single-channel variants)	2-pole terminal block (see Note 3)
• 2 x loop (1 x orange, dual-channel variants)	4-pole terminal block (see Note 3)
Outputs	
• 2 x relays (1 x yellow, 1 x red, R24 variants)	3-pole terminal block (see Note 3) Max. 48 V (AC/DC), 2 A, 60 W, 125 VA (SELV) Min. 1 mA / 5 V (see note 2)
• 4 x open collector (2 x green, O24 variants)	3-pole terminal block (see Note 3) 27 V DC, 25 mA (SELV)
Configuration switch 1 (all variants)	8-pole DIP switch
Configuration switch 2 (dual-channel variants)	4-pole DIP switch
LED status indicator	1 x blue and 1 x red (per loop channel)
Reset button	Push button
PC interface	USB port, type mini AB

Tab. 6: Specifications

NOTE**1) Limitations on loop inductance**

For loop inductances outside the recommended range, only one frequency level may be available.
For very small loop inductances, the maximum loop resistances are lower.

2) Current load of the relay contacts

The rigid gold plating on the relay contacts will be destroyed if the switching current exceeds 100 mA. Relays with contacts that are prestressed in this manner can only reliably switch currents over 100 mA!

3) Terminal block data

Grid dimension 5.0 mm, conductor cross-section 0.25 - 2.5 mm², AWG 24-12

6 Product description

Induction loop detectors such as traffic detectors are electronic sensors for inductive detection of metallic objects. Using induction loops, for example, vehicles are detected, and depending on the device, their design and direction of movement.

The traffic detectors are operated in combination with various induction loops and electronic controller, such as frequency converters or PLC controller.

The areas of application are, for example, the detection, monitoring and counting of vehicles in the areas of traffic engineering, door and barrier controller, parking and tunnel monitoring as well as traffic light systems.

6.1 Product versions

The Verkehrsdetektor is available in the following variants:

Product name	Features
VEK MNH1-R24-A	• 1 Channel for one induction loop • 2 Relay outputs • 8-pole DIP switch for configuration • USB diagnostic interface • Reset button • 24 V supply voltage • TS35 DIN rail mounting • Plastic housing
VEK MNH2-R24-C	• 2 Channels for two induction loops • 2 Relay outputs • 8-pole DIP switch for configuration • 4-pole DIP switch for configuration • USB diagnostic interface • Reset button • 24 V supply voltage • TS35 DIN rail mounting • Plastic housing
VEK MNH2-O24-D	• 2 Channels for two induction loops • 4 Open collector outputs • 8-pole DIP switch for configuration • 4-pole DIP switch for configuration • USB diagnostic interface • Reset button • 24 V supply voltage • TS35 DIN rail mounting • Plastic housing

Tab. 7: Product variants

NOTE**Facilities with high switching frequency**

The use of detectors with digital outputs is recommended for facilities with a high switching frequency. Due to a more limited switching cycle, the operational life of relay contacts is reduced.

6.2 Product characteristics

The traffic detectors have the following properties:

- 1 loop channel (single-channel variants) or 2 loop channels (dual-channel variants)
- 2 potential-free relay outputs with changeover contact (R24 variants)
- 4 open collector outputs (O24 variants)
- 8-pole DIP switch for configuration
- 4-pole DIP switch for advanced configuration
- 2 or 4 LEDs for the indication of detector and loop states
- USB interface for diagnostics and advanced configuration
- Connection for power supply (AC/DC)
- Galvanic isolation between loops and electronics
- Automatic adjustment of the device after switch-on
- Continuous adjustment of frequency drifts to suppress environmental influences
- Sensitivity independent of loop inductance
- Fixed hold times regardless of the loop coverage
- Direction detection based on two loop channels (dual-channel variants)
- Multiplexing prevents mutual interferences of the loop channels (dual-channel variants)
- Compact plastic housing for mounting on DIN rail in control cabinet

6.3 Product functions

The traffic detectors offer the following setting options:

- Switching between two frequency levels
- Output as presence or pulse signal or of loop faults (with *Detector Tool*)
- Response threshold adjustable in 255 steps with *Detector Tool*, in 4 steps with DIP switch
- Hold time adjustable from 1 to 255 minutes and infinite with *Detector Tool*, 5 minutes or infinite with DIP switch
- Counter for loop occupation and travel direction with *Detector Tool*
- Minimum signal duration for output signal with *Detector Tool*
- Switch-in and switch-off delay adjustable with *Detector Tool*
- Hysteresis (drop in threshold value) adjustable from 20 - 80% on each channel with *Detector Tool*
- Detector channels can be switched off with *Detector Tool*
- Comprehensive diagnostic function with *Detector Tool*

Advanced functions of the dual-channel variants:

- Output as presence, pulse or direction signal (dual-channel variant) or loop faults (with *Detector Tool*)
- Selection of direction logic

6.3.1 Vehicle detection

Whether a metallic object is located in the loop area is identified via an LC oscillator (electrical oscillatory circuit). The channel output is switched according to the output function configured.

6.3.2 Output signals

Depending on the output configuration, presence, pulse or direction signals or direction logics as well as loop faults are output.

For the pulse signal, it is also possible to select whether an output should occur when a loop is driven past or vacated.

In addition to inversion of the output signal, both outputs can individually be permanently switched on or off.

6.3.3 Alignment of the loop channels

When the detector is switched on or the reset button on the front is pressed for one second, an alignment of the loop channels is run.

If there has been an interruption of power, an automatic alignment only takes place if the operating voltage has been interrupted for at least 0.5 seconds. Alignment takes around one second if no vehicles drive over the loop in this time.

External influences on the loop frequency may result in longer alignment times, and their causes must be determined and eliminated.

6.3.4 Scanning of the loop channels

The dual-channel traffic detector can evaluate two loop channels.

The timed scanning of the loops is carried out in multiplex mode. They are connected to the common oscillatory circuit oscillator over a multiplexer. This prevents the loops interfering with each other.

The connected induction loops are switched on and off in rapid succession. Current is only ever supplied to one loop at a time. This means that both loops can be operated at the same frequency.

The cycle time of a scan in multiplex mode is 12 ms.

6.3.5 Loop error detection

Loop closure and *loop break* are identified as loop errors.

If no induction loop is connected to the loop channel, this corresponds to a *loop break* error status.

Once a loop error has been detected, the loop channel switches off. This may cause the available operating modes to be restricted, for example direction detection.

When one loop channel is switched off by the *Detector Tool*, this does not affect the second, connected loop channel (2 channel versions).

7 Description of connections

In the following section, the connections for the inputs and outputs are described.

7.1 Power supply

The detector can be operated with direct or alternating current , according to the requirements for Safety Extra-Low Voltages (SELV) of Protection Class III.

WARNING

Note the permitted power supply

Comply with the technical data and safety instructions!

Die Spannungsversorgung wird an den blauen Klemmenblock angeschlossen. The power supply is connected to the blue terminal block.




Fig. 4: Power supply connection (blue)

7.2 Loop inputs

Up to two analogue inputs for the induction loops on the terminal block are located on the underside of the traffic detector. The terminal block is either 2-pole or 4-pole, depending on the product variant.

The induction loops are connected to the orange terminal blocks as shown in the illustration.




Fig. 5: Loop connections (orange)

7.3 Signal outputs

VEK MNH series detectors are available in variants with relay outputs (R24) and with open collector bipolar transistors (O24).

The relay variants are intended particularly for situations which require mechanical switches with high power outputs.

The open collector outputs are primarily intended for applications with high switching rates and low output power, e.g. PLC controller.

Each signal output can be inverted. In this case, when the power supply is turned on, normally open contacts function as normally closed contacts, and vice versa. This happens by switching between open circuit and closed circuit principle.

Loop faults can also be interpreted as *loop covered* or as *loop free*.

Status	Normally closed contact (NC)		Normally open contact (NO)	
	Not inverted (open circuit)	Inverted (closed circuit)	Not inverted (open circuit)	Inverted (closed circuit)
Voltage off				
Detector ready, loop free				
Loop covered				
Loop failure	(loop covered by default, configurable as loop free with Detector Tool)			

Tab. 8: Switching states of the signal outputs

7.3.1 Relay outputs with changeover contact

The relay outputs are designed as changeover contacts. This allows the contacts to be connected as normally closed (NC) or as normally open (NO) contacts. The relays are potential-free and suitable for many different switching modes.

The analogue outputs of the (R24) relay variants are connected to the red and yellow terminal blocks as shown in the following illustration.




Fig. 6: Relay connections 1 (yellow) and 2 (red)

7.3.2 Open collector outputs

The detector with four open collector outputs switches to GND (emitter) when triggered.

For each loop channel, one signal output is provided for the coverage status (object detection) and one output for malfunctions (fault signal).

The digital outputs of the open-collector variants (O24) are connected to the green terminal blocks as shown in the following illustration.




Fig. 7: Open collector connections 1-2 and 3-4 (green)

8 Assembly and electrical installation

In the following section, assembly and electrical installation are described.

NOTE

Illustrations and technical data on the device

You can find illustrations and technical data on the housing and connections in the sections at the beginning of this document.

8.1 Assembly on the DIN rail TS35

Prerequisites

Assembly conditions

Tools: none

Mounting device: DIN rail TS35

Fixing to the DIN rail

1. Place the device from above with the groove onto the top hat rail and lock the clip underneath.
2. Check that it is sitting securely.
 - The detector is ready for commissioning.

8.2 Connecting the power supply

WARNING

Maintain the permitted voltage

The following power supplies are permitted:

- 10 - 30 VDC
- 10 - 26 VAC

Also refer to chapter *Description of connections*.

PREREQUISITES

Connect the inputs and outputs with no voltage present

All inputs and outputs must be connected before switching on the power supply.

TOOLS

- Insulated slotted screwdriver (width: 2 – 3 mm)

Connecting the power cable

1. Follow the warning and safety instructions and take the appropriate precautions.
2. If necessary, pull the terminal block out of the socket.
3. Loosen the screws on the blue terminal block.
4. Insert up to 5 mm of stripped cable into the slot at the side of the blue terminal block and fasten.
5. Tighten the screw.
6. If necessary, insert the terminal block back into the blue 2-pole socket.
 - The power cable is firmly attached to the terminal block with no exposed wires.

Attach the power cable to the power source

1. Comply with the warning and safety instructions for the external device.
2. Follow the manufacturer's instructions on wiring the outputs on the external device.
→ The power cable is connected to the power source.

8.3 Connect the relay outputs (versions -R24)

TOOLS

Insulated slotted screwdriver (width 2 – 3 mm)

Connecting the relay outputs

1. Follow the warning and safety instructions and take the appropriate precautions.
2. If necessary, pull the red or yellow terminal block out of the socket.
3. Loosen the screws on the blue terminal block.
4. Insert up to 5 mm of stripped cable into the slot on the side of the terminal block and fasten.
5. Tighten the screw.
6. If necessary, insert the terminal block back into the red or yellow 3-pole socket.
→ The cables of the relay outputs are firmly attached to the terminal block with no exposed wires.

Connect the relay cable to the external device

1. Comply with the warning and safety instructions for the external device.
2. Follow the manufacturer's instructions on wiring the outputs on the external device.
→ The relay outputs are connected to the signal outputs on the external device.

8.4 Connecting the open collector outputs (versions -O24)

TOOLS

Insulated slotted screwdriver (width: 2 – 3 mm)

Connecting the open collector outputs

1. Follow the warning and safety instructions and take the appropriate precautions.
2. If necessary, pull the green terminal block out of the socket.
3. Loosen the screws on the blue terminal block.
4. Insert up to 5 mm of stripped cable into the slot on the side of the terminal block and fasten.
5. Tighten the screw.
6. If necessary, insert the terminal block back into the green 3-pole socket.
→ The cables of the open collector outputs are firmly attached with no exposed wires.

Connecting the external device

1. Comply with the warning and safety instructions for the external device.
2. Follow the manufacturer's instructions on wiring the outputs on the external device.
→ The relay outputs are connected to the signal outputs on the external device.

8.5 Connecting the induction loops

RECOMMENDATIONS

The requirements for the induction loops differ according to the area of application. Allow the supplier to advise you on installation of the induction loops.

PREREQUISITES

The induction loops are already installed and ready for use.

TOOLS

- Insulated slotted screwdriver (width: 2 – 3 mm)
 - Induction loops for the respective area of application
-

Connecting the induction loops

1. Follow the warning and safety instructions and take the appropriate precautions.
2. If necessary, pull the orange terminal block out of the socket.
3. Loosen the screws on the blue terminal block.
4. Insert up to 5 mm of stripped cable into the slot on the side of the terminal block and fasten.
5. Tighten the screw.
6. If necessary, insert the terminal block back into the orange 4-pole socket.
 - The induction loops are firmly attached with no exposed wires.

9 Commissioning

Prerequisites

Assembly and electrical connection

- The system is not in use.
 - The work must be carried out by qualified specialists.
 - All available cables are firmly attached to the terminal block.
 - The terminal blocks are sited in the input and output sockets of the same colour.
 - The detector is firmly mounted on the top hat rail.
-

Tools

Tools for the system

- Always observe the manufacturer's instructions!
 - No tools are required to commission the system.
-

Commissioning the detector

1. Define the settings with the DIP switches.
2. Switch the power supply to the detector on.
 - The VEK MNH series detectors automatically run a test of the induction loops as well as a frequency alignment.
 - The detector is ready for operation when the blue LEDs are continuously lit. There is more information in the section on LED indicators.
3. Start up all components of the system (observe the manufacturer's instructions).
4. Carry out a functional test of the system (observe the manufacturer's instructions).
 - The detector is ready for continuous operation.

NOTE

Customizing the detector's settings

The device settings can be changed during operation using the DIP switches.

The detector can be customized using the software *Detector Tool* via USB interface.

Read more about the configuration in the chapters about the DIP switches and the *Detector Tool*.

10 Description of functions

In the following section the indicator and control elements are described.

NOTE

Information in this document

This document refers to the default settings or default values defined by the manufacturer. The factory settings of customer variants may differ from the manufacturer's specifications. Please observe the instructions on the device, as well as the documents supplied with it.

10.1 LED status indicators

The LEDs (light emitting diodes) on the front side indicate the state of the loops and the detector.

There are two LEDs for each loop channel:

- The red LED indicates the coverage status of the respective loop
- The blue LED indicates the operating status of the detector

Red LED	Blue LED	Description of status
		No power supply, detector inactive
		Detector ready, loop connected, no object detected
		Detector ready, loop connected, object detected
		No loop connected, loop break, loop closure
	 1 Hz	Ready for operation following earlier, now rectified, loop error or settings changed with <i>Detector Tool</i> (DIP switch not up-to-date)
	 5 Hz	Frequency alignment is running
		After frequency adjustment, both LEDs simultaneously display the set loop frequency in a flash code (see <i>Flash code</i> illustrated example)

Tab. 9: LED signal colours

Key to LED symbols

	Lit up		Off
	Flashing		Frequency

LED flash code following a frequency alignment




Fig. 8: LED display of loop frequency

NOTE

LED position

The LEDs for the loop channel 1 are located at the top or side of the device, for loop channel 2 are in the middle.

10.2 DIP switch settings

NOTE

Further information

- You can find detailed information on settings options in the section *Description of settings*.
- The *Detector Tool* service program offers further settings options. For information on these, read the section on the *Detector Tool*.
- If the settings are changed with the *Detector Tool*, the DIP switch settings are no longer valid. This will be indicated by the blue LEDs flashing. Also read the section on the Reset button.

Function	Description
Sensitivity	Switch-on threshold for the signal output when a loop is covered
Frequency level	Frequency of the loop oscillating circuit in two levels
Hold time until readjustment	Maximum duration of the output signal up to the automatic frequency readjustment of the loop channel
Output signal 2 mode	Switching between continuous and pulse signal on output 2
Output signal 2 time	Time of output signal for activated pulse signal on output 2
Output signal inversion	Switching between open circuit (not inverted) and closed circuit principle (inverted) for the output signals
Direction detection	Switching between presence and travel direction detection for both outputs (dual-channel variants)
Direction Logic	Evaluation logic of the travel direction when loops are covered, depending on the application (see full operating manual!)

Tab. 10: Description of the settings

The single-channel variants have an 8-pole DIP switch for configuring the detector.

DIP	Designation	Function
1	Sense a	Loop 1 sensitivity
2	Sense b	Loop 1 sensitivity
3	Frequency	Frequency step
4	Hold time	Hold time until readjustment
5	Output 2	Output signal 2 mode
6	Edge 2	Output signal 2 time
7	Inv. Out 1	Output signal 1 inversion
8	Inv. Out 2	Output signal 2 inversion

Tab. 11: DIP switch assignment (default)

The following parameters can be adjusted with the DIP switch:

DIP switch	Position	Value
Sense a	ON	0.01% (high)
Sense b	ON	
Sense a	OFF	0,04%
Sense b	ON	
Sense a	ON	0,16%
Sense b	OFF	
Sense a	OFF	0.64% (low)
Sense b	OFF	
Frequency	OFF	low
	ON	high
Hold time	OFF	5 minutes
	ON	Infinite
Output 2	OFF	Continuous signal
	ON	Pulse signal
Edge 2	OFF	on entering
	ON	on leaving
Inv. Out 1	OFF	inverted
	ON	not inverted
Inv. Out 2	OFF	not inverted
	ON	inverted

Tab. 12: Settings via DIP switch (single-channel)

The dual-channel variants have an 8-pole and 4-pole DIP switch for configuring the detector.

DIP1	Designation	Function
1	Sense 1a	Loop 1 sensitivity
2	Sense 1b	Loop 1 sensitivity
3	Sense 2a	Loop 2 sensitivity
4	Sense 2b	Loop 2 sensitivity
5	Frequency	Frequency level
6	Hold time	Hold time until readjustment
7	Output 2	Output signal 2 mode
8	Edge 2	Output signal 2 time

Tab. 13: DIP switch 1 assignment (standard)

DIP2	Designation	Function
1	Dir. Mode	Direction detection
2	Dir. Logic	Direction Logic
3	Inv. Out 1	Output signal 1 inversion
4	Inv. Out 2	Output signal 2 inversion

Tab. 14: DIP switch 2 assignment (standard)

The following parameters can be adjusted with the DIP switch:

DIP switch	Position	Value
Sense 1a / 2a	ON	0.01% (high)
Sense 1b / 2b	ON	
Sense 1a / 2a	OFF	0,04%
Sense 1b / 2b	ON	
Sense 1a / 2a	ON	0,16%
Sense 1b / 2b	OFF	
Sense 1a / 2a	OFF	0.64% (low)
Sense 1b / 2b	OFF	
Frequency	OFF	low
	ON	high
Hold time	OFF	5 minutes
	ON	Infinite
Output 2	OFF	Continuous signal
	ON	Pulse signal
Edge 2	OFF	on entering
	ON	on leaving
Inv. Out 1	OFF	inverted
	ON	not inverted
Inv. Out 2	OFF	not inverted
	ON	inverted
Dir. Mode	OFF	Presence
	ON	Direction
Dir. Logic	OFF	Continuous signal 2
	ON	Wrong-way driver 1

Tab. 15: Settings via DIP switch (dual-channel)

10.3 Reset button

The device is reset using the reset button on the front as follows:

Function	Description	Press button	LED
reset / readjustment	runs a frequency readjustment and clears the LED fault messages	1 second	red LED flashes
factory settings	resets the device to factory settings (DIP switch default settings)	5 seconds	blue LED flashes

Tab. 16: Reset functions

10.4 USB interface

Detailed configuration and diagnosis of the detector data are possible via the USB interface.

The free *Detector Tool* service program can be downloaded from the customer area at www.feig.de. In addition, a computer and a USB cable of the Mini-AB type are required.

10.5 *Detector Tool* service program

NOTE

Registered users may download the *Detector Tool* free of charge from the download area under www.feig.de.

You can find detailed information on the diagnostic functions and advanced configuration options in the guide to the *Detector Tool*. The guide is also available in the download area.

NOTE

Overwriting the DIP switch

Changes made with the *Detector Tool* overwrite the DIP switch settings. When this happens, the blue LEDs flash continuously. In this case, the DIP switch positions may no longer be valid. Pressing the reset button for 5 seconds resets to the factory settings and clears the LEDs (see section *Reset button*).

Configuring the detector

The *Detector Tool* offers additional settings and parameters for configuring the device on top of those offered by the DIP switches. These include, for example, loop sensitivity, hysteresis (drop in threshold value), hold time, behaviour in the event of loop errors, output signal functions, direction detection and switch-on or switch-off delay on the relays.

Diagnostic data indicator

You can evaluate the current diagnostic data with the *Detector Tool*. These include, for example, loop frequency, detuning of the induction loops and their chronological sequences, the current status of the loops, the last maximum retuning, the last occupancy duration, the period between two occupancies, the elapsed hold time, the status of the relays, and the travel direction detected.

The following illustration shows the process of loop detuning by vehicles.




Fig. 9: Detector Tool diagnostic view

11 Description of settings

The functions described below can be performed with the *Detector Tool* service program as well as with the DIP switch. The DIP switch provides the key default settings. Commissioning is not possible without the service program.

NOTE

- You can run diagnostics and perform further settings with the *Detector Tool*.
- If the settings are changed with the *Detector Tool*, the blue LEDs flash continuously.
- In order to reset to factory settings, hold the reset button down for 5 seconds.

Key to tables	
()	Printed designations of the default versions and designations provided in the <i>Detector Tool</i> are show in brackets.
DIP	Information in this column shows the settings options for the DIP switch.
Detector Tool	Information in this column shows the settings available in the <i>Detector Tool</i> .

NOTE

Information in this document

This document refers to the default settings or default values defined by the manufacturer. The factory settings of customer variants may differ from the manufacturer's specifications. Please observe the instructions on the device, as well as the documents supplied with it.

11.1 Adjusting sensitivity (switch-on threshold)

The switch-on threshold can be selected in 255 increments in the range between 0.01% and 2.55% $\Delta f/f$. The higher the switch-on threshold, the lower is the sensitivity for signal activation.

Typical settings

- Generally speaking, sensitivity is adjusted in large steps, and the switch-on threshold selected is not greater than 640.
- Switch-on thresholds of over 640 and fine tuning may not be required for differentiation between vehicles. It is possible to differentiate, for example, buses with large loops (e.g. 10.0 m x 2.5 m) and correspondingly high threshold values (>1000).

NOTE

Minimising interference factors

In order to minimise interference factors, the sensitivity should be as low as possible, i.e. the value of the switch-on threshold should be as high as possible.

DIP (Sense a)	DIP (Sense b)	Detector Tool (switch-on threshold)	Sensitivity ($\Delta f/f$)
ON	ON	10	0.01 % Level high (highest sensitivity)
		20	0.02%
		30	0.03%
OFF	ON	40	0.04% Level medium-high
		50	0.05%
		...	...
		150	0.15%
ON	OFF	160	0.16% Level medium-low
		170	0.17%
		...	...
		630	0.63%
OFF	OFF	640	0.64% level medium-low (factory setting)
		650	0.65%
		...	...
		1000	1.00%
		...	...
		2550	2.55% Level minimum (lowest sensitivity)

Tab. 17: Sensitivity settings

11.2 Setting hysteresis (switch-off threshold)

In order to prevent any intermittent cut-out in the coverage signal in the case of vehicles with high substructures such as articulated buses, trams or HGVs with trailers, it is possible to change the switching hysteresis (switch-off threshold). Interruption-free detection of critical vehicles is then also possible at a lower sensitivity.




Fig. 10: Switch-off threshold hysteresis

Symbol	Description
SV (Δf)	Loop detuning by vehicle
ES	Switch-on threshold (reference value 100 %)
75 %	Switch-off threshold at 75 % of the switch-on threshold
25 %	Switch-off threshold at 25 % of the switch-on threshold
Output (...)	Signal output at 75 % or 25 % hysteresis
t	Duration

Tab. 18: Key to symbols

NOTE

Setting the hysteresis

The hysteresis is set in the *Detector Tool*.

DIP	Detector Tool (hysteresis)	Switch-off threshold (hysteresis in % of the switch-on threshold)
	20 %	minimal (low switch-off threshold)
	...	...
	75 %	(factory setting)
	...	...
	80 %	maximum (high switch-off threshold)

Tab. 19: Hysteresis settings

Switch-off threshold indicator

In the *Detector Tool*, the switch-off threshold is displayed as a multiplication of the hysteresis (%) with the switch-on threshold (absolute value). The absolute value of the switch-off threshold thus changes analogously to the hysteresis.

Examples

In the case of a switch-on threshold of 160 and varying hystereses, the switch-off threshold is calculated as follows:

Hysteresis 75% → cut-out threshold value: 0.75 160 120

Hysteresis 20 % → cut-out threshold value: 0.20 160 32

11.3 Setting loop frequency (frequency step)

The operating frequency setting serves to prevent couplings.

Interference between loops

Couplings may occur between adjacent loops or loop connections from other detectors. Therefore, loops less than 2 metres apart should not operate at the same loop frequency. In this case a frequency spacing of at least 5 kHz must be maintained.

Loop frequency indicator

The operating frequency of the loops after switching on or changes is reflected with an LED flash sequence and can be read off in the *Detector Tool*.

Multiplexing

No coupling between the loops of a detector takes place through multiplexing (2 channel version). The loops on a detector may therefore operate on the same frequency.

WARNING

Deactivating free loop channels

Loop channels with no permanently connected induction loops should be switched off in the *Detector Tool*. If this is not done, a cyclical request is made asking whether an available induction loop has yet been connected. Under unfavourable circumstances this can sporadically lead to interference on the intact loop channels.

NOTE

Loop inductivity range

In the event of loop inductivity outside the recommended range, the available frequency range may be restricted.

DIP (frequency)	Detector Tool	Frequency step
OFF	Low	low (factory setting)
ON	High	High
	Off	none (loop channel switched off)

Tab. 20: Loop frequency settings

11.4 Setting hold time

Separate hold times between 1 and 255 minutes can be set at the detector for each channel. The value 0 corresponds to an infinite hold time. If the loop on a detector channel is covered for longer than the set hold time, the detector channel runs a frequency alignment. The current detuning of the loop channel is reset.

Limiting the hold time

Limiting the hold time can be used, for example, to remove the vehicle parking on the loop automatically once the hold time has ended. The loop can then be reused for subsequent vehicles. Permanent activation caused by faults can also be avoided by setting the hold time appropriately.

DIP (hold time)	Detector Tool	Hold time
ON	0	infinite
	1	1 min
	...	...
OFF	5	5 min
	...	...
	255	255 min

Tab. 21: Hold time settings (VEK MNH)

11.5 Setting output mode (signal type)

Various output modes (signal types) can be set for the outputs.

WARNING

Switching off the direction logic (2 channel version)

The direction logic must be switched off to set the output mode, i.e. *Dir. Mode* on the DIP switch must be set to OFF or the direction logic in the Detector Tool must be set to OFF.

DIP (output 2)	Detector Tool	Output signal
OFF	Presence	constant signal (factory setting)
ON	Pulse	Impulse signal
	On	output permanently switched on
	Off	output permanently switched off
	Collective fault	output signal for collective fault
	Loop error	output signal for loop error

Tab. 22: Signal type settings

11.6 Inverting output signal (Signal behaviour)

An inverted or a non-inverted output signal may be selected for all outputs. Also refer to chapters about the signal outputs (see "7.3 Signal outputs", page 23) and DIP switch settings (see "10.2 DIP switch settings", page 30).

NOTE

Monitoring signal behaviour

- Factory defaults can be found in the quick start guide and not in the housing.
- The operating principle used (open circuit or closed circuit) is displayed in the *Detector Tool*.

DIP (Inv. Out 1)	DIP (Inv. Out 2)	Detector Tool	Signal behaviour
ON	ON	not inverted	Signal output according to the open circuit principle
OFF	OFF	inverted	Signal output according to the closed circuit principle

Tab. 23: Inversion of output signal

11.7 Behaviour in the event of loop error (error mode)

The way a loop error is handled and what status the assigned output will take is selected in the *Error Mode* setting.

NOTE

Settings in the Detector Tool

The settings can only be changed in the *Detector Tool*.

DIP	Detector Tool	Error mode
	Occupied	as for occupied loops (factory setting)
	Free	as for free loops
	Error	if the <i>Error</i> checkbox is activated, loop errors for this channel will be transmitted. The <i>Error Mode</i> field then shows as <i>Active</i> (factory setting).
	Alignment	if the <i>Alignment</i> checkbox is activated, the duration of the frequency adjustment of the loop will be considered an error. This option is permanently switched off as the default.

Tab. 24: Error mode settings

11.8 Assigning an output to a loop (Assignment)

A loop channel or a travel direction can be assigned to each output when direction detection is activated (dual-channel variants only).

NOTE

Settings in the Detector Tool

The settings can be changed in the *Detector Tool*.

DIP	Detector Tool	Output switching
	None	Output is inactive
	Channel 1 ¹	when loop 1 is covered (factory setting for output 1)
	Channel 2 ^{1, 3}	when loop 2 is covered (factory setting for output 2)
	Direction A ^{2, 3}	for travel direction A (factory setting for output 1)
	Direction B ^{2, 3}	for travel direction B (factory setting for output 2)
	Direction A & B ^{2, 3}	for both travel directions

Tab. 25: Assigning the outputs

NOTE

¹ when detuning loops for larger approach thresholds and when direction detection is switched off

² when direction detection is activated

³ for dual-channel variants

11.9 Setting output switching time (impulse time)

The switching time for the outputs can be defined in impulse signal mode.

NOTE**Set impulse duration**

The default impulse duration is 200 ms. This can be changed in the *Detector Tool* in increments of 100 ms.

DIP (edge 2)	Detector Tool	Impulse time
OFF	Drive past	when the loop is driven past (factory setting)
ON	Vacant	when the loop is freed up

Tab. 26: Output impulse time

11.10 Setting output times (output time behaviour)

The switch-on delay, the switch-off delay and the minimum signal duration for the output signals can be set in the range from 0 to 25,500 ms in increments of 100 ms.

NOTE**Switch-on delay with short loop coverage**

If the loop becomes free before the switch-on delay has expired, no signal is output.

Settings with the *Detector Tool*

The settings can only be changed with the *Detector Tool*.

DIP	Detector Tool	Output time behaviour
	0 – 25,500 ms, Δ 100 ms	Switch-on delay (factory setting: 0 ms)
	0 – 25,500 ms, Δ 100 ms	Switch-off delay (factory setting: 0 ms)
	0 – 25,500 ms, Δ 100 ms	Minimum signal duration (factory setting: 200 ms)

Tab. 27: Duration of output signal




Fig. 11: Output signal time response

Variable	Description
Loop	Loop coverage
Output	Output signal
t_L	Loop coverage duration
t_s	Output signal duration
t_{MIN}	Minimum signal duration
t_{ON}	Switch-on delay
t_{OFF}	Switch-off delay

Tab. 28: Output times legend

11.11 Setting direction detection (dual-channel variants)

Complex evaluation algorithms are integrated into the dual-channel detector for direction-dependent recording of vehicles over double loops. The direction logic generates logical output signals that are given out over the outputs depending on the setting. Parallel to this, the detector autonomously counts the logic signals.




Fig. 12: Direction detection principle

Symbol	Description
Dir A, Dir B	Direction A: Loop 1→Loop 2 or direction B: Loop 2→1
L1, L2	Loop 1 or 2
Out A, Out B	Signal output direction A or B
LM	Logic module
LOC	Loop coverage counter
DLC	Direction logic counter

Tab. 29: Key to symbols

Direction logic system

- With all the logics, the first loop covered determines the direction of counting or of travel. If loop 1 is covered first, the signal output and counting is done for direction A (see "0 Direction detection principle", page 42).
- In the factory settings, travel direction A is output via hardware output 1, and travel direction B via hardware output 2. The assignment of the signal outputs can be changed (see "11.8 Assigning an output to a loop (Assignment)", page 40).

NOTE

Counter readings in the Detector Tool

- The counter readings are displayed in the *Detector Tool*. It should be noted that the counter overflows at 65,535 (2^{16}) and is automatically erased.
- The counter readings are not protected against power failure!

DIP	Detector Tool	Direction detection
OFF	OFF	Switched off (factory settings)
ON	On	Switched on

Tab. 30: Setting direction detection

11.12 Setting direction logic (dual-channel variants)

A variety of evaluation logics can be set in the logic module, depending on the application.

NOTE

Switching direction detection on

It is only possible to set the direction logic when direction detection is activated!

DIP (Dir. Logic)	Detector Tool	Direction Logic
	D1	Continuous signal 1
	DB	Continuous signal, both loops
OFF	D2	Constant signal 2 (factory setting)
ON	F1	wrong-way driver 1
	F2	Wrong-way driver 2
	BS	both loops
	FE	Feig
	SF	Loop free
	PB	Parking bay
	OFF	No logic selected

Tab. 31: Setting direction logic

The different logics for direction detection are described below.

abbr.	Direction Logic	Signal output	Signal drop	Note
D1	Continuous signal 1	Covering Loop 1	Leaving Loop 1	Output signal in opposite direction only occurs again if both loops were previously free.
DB	Continuous signal both		Leaving Loop 2	
D2	Continuous signal 2	Covering Loop 2		
F1	Wrong-way driver 1	Covering Loop 2	Pulse output with minimum signal duration (default: 200 ms)	Correct behaviour in the case of queues and manoeuvring. Different behaviour in wrong-way driver situation.
F2	Wrong-way driver 2			Correct behaviour in the case of queues. Manoeuvring should not occur.
BS	both loops			Correct behaviour in the case of queues and manoeuvring.
FE	Feig	Leaving Loop 1		Correct behaviour in the case of queues and manoeuvring.
SF	Loop free	Leaving Loop 2		Recording single vehicles and manoeuvring. Queues should not occur.

abbr.	Direction Logic	Signal output	Signal drop	Note
PB	Parking bay	Direction-dependent		For short entrances and exits
Ri1	Direction 1			
Ri2	Direction 2			

Tab. 32: Overview of direction logic

Symbol	Description
	Highlighted direction logic delivers false counts for this setting
	Pulse signal travel direction A
	Pulse signal travel direction B
	Continuous signal
	Loop free
	Loop covered

Tab. 33: Key to direction logic

You can find information on the detailed functions for different traffic situations in the following section.

11.12.1 "Single vehicle" direction logic



	D2	D1	DB	F1	F2	FE	SF	BS	PB Ri1 Ri2	
										
										
										
										
										

Fig. 13: Single vehicle direction logic

11.12.2 "Queue" direction logic






	D2	D1	DB	F1	F2	FE	SF	BS	PB Ri1	PB Ri2
										
				A	A			A		
						A				A
										
									B	
				A	A			A		
						A				A
							A		A	

Fig. 14: Queue direction logic

11.12.3 "Wrong-way driver" 1 direction logic



	D2	D1	DB	F1	F2	FE	SF	BS	PB Ri1	PB Ri2
										
				A	A			A		
										
				B	B					

Fig. 15: Wrong-way driver 1 direction logic

11.12.4 "Wrong way driver 2" direction logic

	D2	D1	DB	F1	F2	FE	SF	BS	PB	
									Ri1	Ri2
				A	A			A		
						A				A
									B	
					B					

Fig. 16: Wrong-way driver 2 direction logic

11.12.5 "Manoeuvring" 1 direction logic

	D2	D1	DB	F1	F2	FE	SF	BS	PB	
									Ri1	Ri2
				A	A			A		
						A				A
							A		A	

Fig. 17: Manoeuvring 1 direction logic

11.12.6 "Manoeuvring" 2 direction logic


	D2	D1	DB	F1	F2	FE	SF	BS	PB	
									Ri1	Ri2
										
				A	A			A		
						A				A
										
									B	
				A	A			A		
						A				A
							A		A	

Fig. 18: Manoeuvring 2 direction logic

11.12.7 "Wrong-way driver in queue" direction logic





	D2	D1	DB	F1	F2	FE	SF	BS	PB	
									Ri1	Ri2
										
				A	A			A		
						A				A
										
									B	
					B					

Fig. 19: "Wrong-way driver in queue" direction logic

11.12.8 Direction Logic „Cross traffic“

		D2	D1	DB	F1	F2	FE	SF	BS	PB	
										Ri1	Ri2
					A	A			A		
							A				A
										B	
						B					

Fig. 20: Cross traffic direction logic

NOTE

False counts

All logics except logic PB in direction 1 deliver false counts in this traffic situation, because they count entries instead of exits!

11.12.9 Direction Logic „Parking bay“

This direction logic is used where for short entrances and exits. Interference to counting due to cross traffic on loop 1 is disabled in this logic. This logic suppresses the impairment of counting by cross traffic on loop 1. It is therefore irrelevant whether loop 1 is laid in the adjoining lane or the manoeuvring area.

WARNING

Positioning of the loops

The positioning of the loops is dependent on the direction in which congestion is anticipated. No tailbacks are permitted to occur in travel direction 1 → 2. In travel direction 2 → 1, vehicles will also be correctly counted in congestion, and in this situation the gap between vehicles must release one loop at a time.




Fig. 21: Parking bay Direction Logic

Symbol	Description
A	passageway
B	Car park
1	Loop 1
2	Loop 2

Tab. 34: Symbols for parking bay

Logic for travel direction 1 → 2

- The counting pulse is triggered as soon as both loops have been completely crossed
- Correct counting with single vehicles
- Correct counting also with manoeuvring
- Congestion and queues are not permitted to occur in travel direction 1 → 2!

Logic for travel direction 2 → 1

- The counting pulse is triggered as soon as loop 2 is vacated in the direction of loop 1.
- Correct counting also with cross traffic
- Correct counting with queues
- Correct counting also when a single vehicle is manoeuvring
- No manoeuvring is permitted to take place in a queue!

12 Maintenance & servicing

NOTE

Maintenance and repairs

This product does not require any maintenance or servicing.

In the event of malfunctions and faults, please contact the vendor or the manufacturer.

13 Decommissioning

Conditions

System not functioning

The system is not in use.

All work must be carried out by qualified specialists.

Tools

Tools for the system

Always comply with the manufacturer's instructions!

Insulated slotted screwdriver (width 2 – 3 mm)

Decommissioning the detector

1. Switch off all components of the system (observe the manufacturer's instructions).
2. Switch off the power supply to the detector.
3. Check that there is no voltage to any of the supply cables.
 - The detector can be detached.
4. Carefully press down the mounting bracket with the screwdriver and pull the detector off the DIN rail.
5. Pull the terminal blocks out of the input and output sockets.
 - The detector can be detached. Remove all connectors as follows:
6. Loosen the screws holding the terminal blocks with a slotted screwdriver.
7. Pull the cable out of the mounting slots.
 - The detector is disassembled.



At the end of its service life, dispose of the product in accordance with the valid legal specifications.

14 Key words

A

Alternating current	25
Analogue outputs	26

B

Basic settings	35, 37
Bipolar transistors	26, 27

C

Changeover contact	26
Closed circuit principle	26
Configuration	35, 37, 40
Connecting the loops	31
Connecting the open collector	30
Connecting the power supply	29
Connections	18, 25
Continuous signal	48
Counter readings	47
Coverage status	33
Cross traffic	53

D

Default settings	10, 33, 35, 37, 40
Detector Tool	38
Device components	18
Device configuration	38
Diagnostic data	38
Diagnostic interface	38
Diagnostic program	38
Digital output	27
DIN rail	29
DIP switch	18, 35, 44
Direct current	25
Direction detection	45, 47
Direction Logic	47

E

Error mode	44
------------------	----

F

factory settings	10, 33, 40
Factory settings	35, 37
False counts	49
Flash code	33
Frequency alignment	33
Frequency step	42
Fresh alignment	24
Functions	40

I

Impulse signal	45
Impulse time	45
Indicator	18
Induction loop	31
Inputs	18, 25
Interface	38
Interference	42
Interpreting travel direction	48
Inversion	26, 44
Inverting output signal	44

L

Labelling	18
LED	18
LED indicator	33
Loop alignment	24
Loop assignment	45, 47
Loop break	24
Loop closure	24
Loop error	24, 44
Loop errors	33
Loop inputs	25
Loop occupancy	45, 47
Loop scanning	24
Loop status	44

M

Manoeuvring	51
Minimum signal duration	46
Multiplexing	24, 43

N

Normally closed contact	26
Normally open contact	26

O

Open circuit principle	26
Open collector outputs	26, 27
Operation	18
Oscillatory circuit oscillator	24
Output assignment	45, 47
Output signal	24, 44
Output signals	46
Output time behaviour	46
Outputs	18, 26, 44

P

Parking bay	48, 53
-------------------	--------

Positioning of the loops.....	53	Signal outputs	26, 44
Power supply	25	Signal type	43
Pulse signal	49	Single vehicle	49
Q		Status indicators	33
Queue	50	Switch.....	35, 44
R		Switch status	26
Relay	26	Switching time	45
Relay outputs	26	Switch-off delay	46
reset button	18, 37	Switch-off threshold	41
S		Switch-on delay	46
Safety Extra-Low Voltage	25	Switch-on threshold	40
Sensitivity	40	T	
Service interface	38	Terminal block.....	18
Service program	38	Top hat rail	29
Setting direction detection	47	Traffic Detector	18
Setting direction logic.....	48	Travel direction	49
Setting hold time	43	U	
Setting hysteresis	41	USB.....	38
Setting loop frequency	42	USB connection	18
Setting output mode.....	43	V	
Settings	18, 35, 37, 40	Vehicle detection.....	24
Short circuit.....	24	W	
Signal behaviour	44	Wrong-way driver	48, 50
Signal output.....	26		

15 Appendix

15.1 Accessories

Item no.	Designation	Description
4405	VEK USB cable	2.0 m USB cable type A to mini AB

Tab. 35: separately available accessories

15.2 Declaration of conformity



The EU Declaration of Conformity is available on the Internet at the following address:
<https://www.feig.de/downloads/>

Declaration of Conformity



in accordance with the
Electromagnetic Compatibility (EMC)
Directive 2014/30/EU
and
RoHS 2 Directive 2011/65/EU
and amendment
Directive 2015/863/EU

Product Manufacturer : **FEIG ELECTRONIC GmbH**
 Lange Strasse 4
 D-35781 Weilburg
 Germany
 Phone +49 6471 3109 0

Product Designation : **VEK MNH1-R24-A**
VEK MNH2-R24-C
VEK MNH2-O24-D

Product Description : 1 & 2-Channel Induction Loop Detector

FEIG ELECTRONIC GmbH herewith declares the conformity of the product with applicable regulations below.

Standards applied :

Electromagnetic compatibility (EMC) **DIN EN 61000-6-2:2005**
 Part 6-2: Generic Standards
 Immunity for industrial environments

Electromagnetic compatibility (EMC) **DIN EN 61000-6-3:2007**
 Part 6-3: Generic standards **/ A1:2011 / AC:2012**
 Emission standard for residential, commercial and
 light-industrial environments

Weilburg-Waldhausen, 04/06/2019

Place & date of issue

Dirk Schäfer 
 Name and signature

This declaration attests to conformity with the named Directives but does not represent assurance of properties.
 The safety guidelines in the accompanying product documentation must be observed.

Abb. 22: EU Declaration of Conformity

Other ManualsLib Projects

 www.manualslib.com

 www.manualslib.de

 www.manualslib.es

 www.manualslib.fr

 www.manualslib.nl

 www.manualslib.mx

 www.manualslib.tech 30+ Languages